HAVAL

HAVAL JOLION PRO HEV


SUV

From 2024









Legend

	Airbag		Airbag inflator/ stored gas inflator	Seat belt pretensioner		SRS control unit
	Gas strut, preloaded spring		High strength zone	Zone requiring special attention	000 000	Battery, low-voltage
2	High voltage power cable	<u> </u>	Battery pack, high- voltage	Fuel tank content gasoline / ethanol	⊘	Low voltage device that disconnects high voltage
4	High voltage component					

This overview shows the maximum range of equipment of the vehicle.	ID No.	Version No.	Page No.	
	LGW-HAVAL-JOLION PRO HEV-1	V1	1/4	

HAVAL

SUV

From 2024



1. Identification / recognition



LACK OF ENGINE NOISE DOES NOT MEAN VEHICLE IS OFF. SILENT MOVEMENT OR INSTANT RESTART CA-PABILITY EXISTS UNTIL VEHICLE IS FULLY SHUT DOWN. WEAR APPROPRIATE PPE.








2. Immobilisation / stabilisation / lifting


Immobilize vehicle

- 1. Press the P button to engage the parking gear (P).
- 2. Pull up the EPB switch, ensure the vehicle is stationary.
- 3. Shut power off.










Stabilisation-lifting points


Lifting points

3. Disable direct hazards / safety regulations

Turn off the vehicle and keep the smart key away from the vehicle









Disconnecting negative electrode of 12V battery












Disconnecting battery safety switch









This overview shows the maximum range of equipment of the vehicle.

ID No.	Version No.	Page No.	
LGW-HAVAL-JOLION PRO HEV-1	V1	2/4	

HAVAL

HAVAL JOLION PRO HEV

SUV

From 2024



Disconnecting battery safety switch





4. Access to the occupants

High strength steel in body Mechanical seat adjustment




Electrical seat adjustment






WHEN THE 12 V BATTERY IS DISCONNECTED, ELECTRICAL COMPONENTS CANNOT BE OPERATED.

Glass types



5. Stored energy / liquids / gases / solids



6. In case of fire



USE LARGE AMOUNTS OF WATER

If it is difficult to apply copious amounts of water to the high voltage battery, it is recommended to allow the high voltage battery to burn itself out.





BATTERY RE-IGNITION!













DO NOT SUBMERGE VEHICLE TO EXTINGUISH BATTERY.

7. In case of submersion

Proper personal protective equipment should be worn when handling any flooded vehicle. Pull the vehicle out of water as much as possible, immobilize the vehicle and disable the vehicle before starting any operation (refer to chapter 3).

This overview shows the maximum range of equipment of the vehicle.	ID No.	Version No.	Page No.	
	LGW-HAVAL-JOLION PRO HEV-1	V1	3/4	



HAVAL JOLION PRO HEV

SUV

From 2024




Tilt the vehicle to one side to allow water to drain out of the vehicle.


8. Towing / transportation / storage

Location front hook



Location rear hook







STORE AT SAFE DISTANCE FROM OTHER VEHICLES!





BATTERY RE-IGNITION!

9. Important additional information



Driver's seat has a far side airbag in addition to the side airbag. Location of far side airbag is shown in the mark 9. on page 1.

10. Explanation of pictograms used

Pictogram	Designation
%	Low voltage device that disconnect high voltage
	Remove smart key
	Bonnet
□ IR ∭	Use thermal Infrared camera
4	Hybrid Electric Vehicle on fuel of liquid group 2

Pictogram	Designation
	Flammable
	Explosive
	Corrosives
4	Warning, Electricity
≉	Air-conditioning component

Pictogram	Designation	
	Hazardous to the human health	
	Use water to extinguish the fire	
	Boot	
	General warning sign	
	Acute toxicity	

This overview shows the maximum range of equipment of the vehicle.	ID No.	Version No.	Page No.
	LGW-HAVAL-JOLION PRO HEV-1	V1	4/4